

Assembly Instructions | Single Bay

You will need a flat space to work in and two people for this task.

TOOLS: 1 x 17mm Spanner/Socket or Shifter.


Step 1 Assemble uprights

- Lay 2 uprights apart on the floor to the width of a cross brace.
- Position a brace top/middle/bottom as shown.
- Use the included bolt to hold in position - do not tighten yet.



Step 2 Diagonal bracing

- Position the diagonal braces to fit over the bolts.
- Add the nuts and tighten all braces into position using 17mm spanner.



Step 3 First beams

- Stand first upright in position.
- Place bottom beam at desired height & push down to interlock with frame.
- Repeat on the other side.



Step 4 Second upright frame


- Stand other upright in position and repeat.



TIP! Count the number of slots from the ground up so beams are all level when you tap them in.

Step 5 All beams

- Fit the remaining front and rear beams in place using the same method.



Step 6 Insert shelves

- Lay your shelf panels between the top retaining lips of the beams.



Step 7 Insert Locking Pins

- Insert locking pins into each point where shelf beam meets the upright frame (this means 4 pins per complete shelf - 1 pin at each end on both sides).



SAFETY FIRST

It is recommended you fix the unit to the floor using appropriate fixings for the surface to avoid tipping.

